



Electrical connection



- 1 Sensor circuit, channel 1 (4 ... 20 mA), active input
- 2 Sensor circuit, channel 2 (4 ... 20 mA), active input
- 3 Sensor circuit, channel 1 (4 ... 20 mA), passive input
- 4 Sensor circuit, channel 2 (4 ... 20 mA), passive input
- 5 Relay output channel 1
- 6 Relay output channel 2
- 7 Voltage supply

You can find details on electrical connection in the instrument operating instructions on our homepage at www.vega.com/downloads.

Dimensions



Dimensions VEGATOR 142

Information

You can find further information on the VEGA product line on our homepage.

In the download section of our homepage you'll find operating instructions, product information, industry brochures and approval documents as well as device and adjustment software.

Contact

You can find your personal contact person at VEGA on our homepage under "Contact".